

Drivenge arm connection

ON—OFF

1

RES/ACC

2

SET/COAST

3

4

Green

5

Blue

6

Red

7

8

