

<b>DF202 PRESENT OR STORED</b>	<b><u>UCH MULTIPLEX SIGNALS DISABLED</u></b> DEF: Reverse gear signal consistency
--	--

<b>NOTES</b>	<b>Special notes:</b> Even though this is stored in the computer, this fault does not cause the warning lights to come on or a fault message, because the <b>ESP</b> system is not faulty. Perform fault finding on the <b>UCH</b> (Passenger compartment connection unit) using the <b>diagnostic tool</b> . <b>Note:</b> After repairing the fault in the UCH (Passenger compartment connection unit), clear the fault memory in the ESP system.
	<b>Conditions for applying the fault finding procedure to stored faults:</b> The fault is declared present when the engine is started.

Run a check on the <b>UCH</b> (Passenger compartment connection unit) using the <b>diagnostic tool</b> (see <b>87B, Passenger compartment connection unit</b> ).
Run a multiplex network test (see <b>88B, Multiplex</b> ).

<b>AFTER REPAIR</b>	Clear the computer fault memory. Carry out a road test followed by another check with <b>the diagnostic tool</b> . If the fault is still present, contact the Techline.
---------------------	---